

Einstellwerte für gedrehte Kontakte Settings for closed turned contacts



Werkzeuge / Tools 97 52 65 A / 97 52 65 DG A

Hinweis: Das Einstellmaß und die Locator-Position der Crimpzange sind entsprechend dem Leiterquerschnitt anzupassen. Zur Ermittlung der hier aufgeführten Crimpeinstellungen wurde ein handelsübliches, feindrähtiges Litzenkabel verwendet. Die ermittelten Werte sind lediglich Richtgrößen und ohne Gewähr. Die Crimpeinstellungen sind vom Anwender mit der jeweils eingesetzten Litze konkret zu prüfen.

Note: The crimping depth and the locator position on the crimping tool must be adjusted to match the conductor cross-section. A standard, fine-stranded cable was used to determine the crimping settings listed here. The values given are for guidance only and are provided without warranty. The user must verify the crimping settings specifically for the stranded cable being used.

Hersteller Manufacturer	Locator Knipex	Nummer 1 Contact No. 1	Nummer 2 Contact No. 2	Steckerserie (Gehäuse) Connector series (housing)	Crimpkontaktserie Crimp contact series	Einstellmaß Setting dim. [mm]	Querschnitt Cross-section [mm ²]	Locator- position
Intercontec	97 59 65 TE1	60.001.XX	60-0001-011	M17 / M23	617 / 917 / 932 / 623	0,71	0,14	Stift 06
Intercontec	97 59 65 TE1	60.001.XX	60-0001-011	M17 / M23	617 / 917 / 932 / 623	0,81	0,25	Stift 06
Intercontec	97 59 65 TE1	60.001.XX	60-0001-011	M17 / M23	617 / 917 / 932 / 623	0,91	0,35	Stift 06
Intercontec	97 59 65 TE1	60.001.XX	60-0001-011	M17 / M23	617 / 917 / 932 / 623	0,99	0,50	Stift 06
Intercontec	97 59 65 TE1	60.001.XX	60-0001-011	M17 / M23	617 / 917 / 932 / 623	0,99	0,75	Stift 06
Intercontec	97 59 65 TE1	60.001.XX	60-0001-011	M17 / M23	617 / 917 / 932 / 623	1,14	1,00	Stift 06
Intercontec	97 59 65 TE1	60.003.XX	60-0003-011	M32 / M40 / M23	923 / 932 / 940	1,14	0,35	Stift 01
Intercontec	97 59 65 TE1	60.003.XX	60-0003-011	M32 / M40 / M23	923 / 932 / 940	1,14	0,50	Stift 01
Intercontec	97 59 65 TE1	60.003.XX	60-0003-011	M32 / M40 / M23	923 / 932 / 940	1,32	0,75	Stift 01
Intercontec	97 59 65 TE1	60.003.XX	60-0003-011	M32 / M40 / M23	923 / 932 / 940	1,32	1,00	Stift 01
Intercontec	97 59 65 TE1	60.003.XX	60-0003-011	M32 / M40 / M23	923 / 932 / 940	1,50	1,50	Stift 01
Intercontec	97 59 65 TE1	60.003.XX	60-0003-011	M32 / M40 / M23	923 / 932 / 940	1,72	2,50	Stift 01
Intercontec	97 59 65 TE1	60.011.XX	60-0011-011	M17 / M23	617 / 917 / 932 / 623	0,71	0,14	Stift 06
Intercontec	97 59 65 TE1	60.011.XX	60-0011-011	M17 / M23	617 / 917 / 932 / 623	0,81	0,25	Stift 06
Intercontec	97 59 65 TE1	60.011.XX	60-0011-011	M17 / M23	617 / 917 / 932 / 623	0,91	0,35	Stift 06
Intercontec	97 59 65 TE1	60.011.XX	60-0011-011	M17 / M23	617 / 917 / 932 / 623	0,99	0,50	Stift 06
Intercontec	97 59 65 TE1	60.011.XX	60-0011-011	M17 / M23	617 / 917 / 932 / 623	0,99	0,75	Stift 06
Intercontec	97 59 65 TE1	60.011.XX	60-0011-011	M17 / M23	617 / 917 / 932 / 623	1,14	1,00	Stift 06
Intercontec	97 59 65 TE1	60.023.XX	60-0023-011	M32 / M40 / M23	923 / 932 / 940	0,99	2,50	Stift 01
Intercontec	97 59 65 TE1	60.023.XX	60-0023-011	M32 / M40 / M23	923 / 932 / 940	1,14	4,00	Stift 01
Intercontec	97 59 65 TE1	60.241.XX	60-0241-011	M23	923 - X-Tec	1,14	0,35	Stift 01
Intercontec	97 59 65 TE1	60.241.XX	60-0241-011	M23	923 - X-Tec	1,14	0,50	Stift 01
Intercontec	97 59 65 TE1	60.241.XX	60-0241-011	M23	923 - X-Tec	1,32	0,75	Stift 01
Intercontec	97 59 65 TE1	60.241.XX	60-0241-011	M23	923 - X-Tec	1,32	1,00	Stift 01
Intercontec	97 59 65 TE1	60.241.XX	60-0241-011	M23	923 - X-Tec	1,50	1,50	Stift 01
Intercontec	97 59 65 TE1	60.241.XX	60-0241-011	M23	923 - X-Tec	1,72	2,50	Stift 01
Intercontec	97 59 65 TE1	60.254.XX	60-0254-011	M23	923	1,14	0,35	Stift 01
Intercontec	97 59 65 TE1	60.254.XX	60-0254-011	M23	923	1,14	0,50	Stift 01
Intercontec	97 59 65 TE1	60.254.XX	60-0254-011	M23	923	1,32	0,75	Stift 01
Intercontec	97 59 65 TE1	60.254.XX	60-0254-011	M23	923	1,32	1,00	Stift 01
Intercontec	97 59 65 TE1	60.254.XX	60-0254-011	M23	923	1,50	1,50	Stift 01
Intercontec	97 59 65 TE1	60.254.XX	60-0254-011	M23	923	1,72	2,50	Stift 01
Intercontec	97 59 65 TE1	60.302.XX	60-0302-011	M40 / M23	923 / 940	0,99	2,50	Stift 01
Intercontec	97 59 65 TE1	60.302.XX	60-0302-011	M40 / M23	923 / 940	1,14	4,00	Stift 01
Intercontec	97 59 65 TE1	61.004.XX	61-0004-011	M17 / M27 / M23	617 / 627 / 932 / 623	0,71	0,14	Stift 06
Intercontec	97 59 65 TE1	61.004.XX	61-0004-011	M17 / M27 / M23	617 / 627 / 932 / 623	0,81	0,25	Stift 06
Intercontec	97 59 65 TE1	61.004.XX	61-0004-011	M17 / M27 / M23	617 / 627 / 932 / 623	0,91	0,35	Stift 06
Intercontec	97 59 65 TE1	61.004.XX	61-0004-011	M17 / M27 / M23	617 / 627 / 932 / 623	0,99	0,50	Stift 06
Intercontec	97 59 65 TE1	61.004.XX	61-0004-011	M17 / M27 / M23	617 / 627 / 932 / 623	1,14	0,75	Stift 06
Intercontec	97 59 65 TE1	61.009.XX	61-0009-011	M23	923	0,71	0,14	Stift 05
Intercontec	97 59 65 TE1	61.009.XX	61-0009-011	M23	923	0,81	0,25	Stift 05
Intercontec	97 59 65 TE1	61.009.XX	61-0009-011	M23	923	0,91	0,35	Stift 05
Intercontec	97 59 65 TE1	61.009.XX	61-0009-011	M23	923	0,99	0,50	Stift 05
Intercontec	97 59 65 TE1	61.009.XX	61-0009-011	M23	923	0,99	0,75	Stift 05
Intercontec	97 59 65 TE1	61.009.XX	61-0009-011	M23	923	1,14	1,00	Stift 05
Intercontec	97 59 65 TE1	61.010.XX	61-0010-011	M23	923	1,14	0,35	Stift 01
Intercontec	97 59 65 TE1	61.010.XX	61-0010-011	M23	923	1,14	0,50	Stift 01
Intercontec	97 59 65 TE1	61.010.XX	61-0010-011	M23	923	1,32	0,75	Stift 01
Intercontec	97 59 65 TE1	61.010.XX	61-0010-011	M23	923	1,32	1,00	Stift 01
Intercontec	97 59 65 TE1	61.010.XX	61-0010-011	M23	923	1,50	1,50	Stift 01
Intercontec	97 59 65 TE1	61.010.XX	61-0010-011	M23	923	1,72	2,50	Stift 01
Intercontec	97 59 65 TE1	61.020.XX	61-0020-011	M23	923	0,71	0,14	Stift 03
Intercontec	97 59 65 TE1	61.020.XX	61-0020-011	M23	923	0,81	0,25	Stift 03
Intercontec	97 59 65 TE1	61.020.XX	61-0020-011	M23	923	0,91	0,35	Stift 03
Intercontec	97 59 65 TE1	61.020.XX	61-0020-011	M23	923	0,99	0,50	Stift 03
Intercontec	97 59 65 TE1	61.020.XX	61-0020-011	M23	923	0,99	0,75	Stift 03

Hersteller Manufacturer	Locator Knipex	Nummer 1 Contact No. 1	Nummer 2 Contact No. 2	Steckerserie (Gehäuse) Connector series (housing)	Crimpkontaktserie Crimp contact series	Einstellmaß Setting dim. [mm]	Querschnitt Cross-section [mm ²]	Locator- position
Intercontec	97 59 65 TE1	61.020.XX	61-0020-011	M23	923	1,14	1,00	Stift 03
Intercontec	97 59 65 TE1	61.022.XX	61-0022-011	M23	923	1,14	0,35	Stift 01
Intercontec	97 59 65 TE1	61.022.XX	61-0022-011	M23	923	1,14	0,50	Stift 01
Intercontec	97 59 65 TE1	61.022.XX	61-0022-011	M23	923	1,32	0,75	Stift 01
Intercontec	97 59 65 TE1	61.022.XX	61-0022-011	M23	923	1,32	1,00	Stift 01
Intercontec	97 59 65 TE1	61.022.XX	61-0022-011	M23	923	1,50	1,50	Stift 01
Intercontec	97 59 65 TE1	61.022.XX	61-0022-011	M23	923	1,72	2,50	Stift 01
Intercontec	97 59 65 TE1	61.023.XX	61-0023-011	M23	923	0,99	2,50	Stift 01
Intercontec	97 59 65 TE1	61.023.XX	61-0023-011	M23	923	1,14	4,00	Stift 01
Intercontec	97 59 65 TE1	61.027.XX	61-0027-011	M23	923	0,99	2,50	Stift 02
Intercontec	97 59 65 TE1	61.027.XX	61-0027-011	M23	923	1,14	4,00	Stift 02
Intercontec	97 59 65 TE1	61.098.XX	61-0098-011	M40	940	0,81	0,14	Stift 04
Intercontec	97 59 65 TE1	61.098.XX	61-0098-011	M40	940	0,91	0,25	Stift 04
Intercontec	97 59 65 TE1	61.098.XX	61-0098-011	M40	940	0,99	0,35	Stift 04
Intercontec	97 59 65 TE1	61.098.XX	61-0098-011	M40	940	0,99	0,50	Stift 04
Intercontec	97 59 65 TE1	61.107.XX	61-0107-011	M40	940	1,14	0,35	Stift 04
Intercontec	97 59 65 TE1	61.107.XX	61-0107-011	M40	940	1,14	0,50	Stift 04
Intercontec	97 59 65 TE1	61.107.XX	61-0107-011	M40	940	1,32	0,75	Stift 04
Intercontec	97 59 65 TE1	61.107.XX	61-0107-011	M40	940	1,32	1,00	Stift 04
Intercontec	97 59 65 TE1	61.107.XX	61-0107-011	M40	940	1,50	1,50	Stift 04
Intercontec	97 59 65 TE1	61.107.XX	61-0107-011	M40	940	1,72	2,50	Stift 04
Intercontec	97 59 65 TE1	61.193.XX	61-0193-011	M23	923	1,14	0,35	Stift 01
Intercontec	97 59 65 TE1	61.193.XX	61-0193-011	M23	923	1,14	0,50	Stift 01
Intercontec	97 59 65 TE1	61.193.XX	61-0193-011	M23	923	1,32	0,75	Stift 01
Intercontec	97 59 65 TE1	61.193.XX	61-0193-011	M23	923	1,32	1,00	Stift 01
Intercontec	97 59 65 TE1	61.193.XX	61-0193-011	M23	923	1,50	1,50	Stift 01
Intercontec	97 59 65 TE1	61.193.XX	61-0193-011	M23	923	1,72	2,50	Stift 01
Intercontec	97 59 65 TE1	61.194.XX	61-0194-011	M23	923	0,81	0,14	Stift 01
Intercontec	97 59 65 TE1	61.194.XX	61-0194-011	M23	923	0,91	0,25	Stift 01
Intercontec	97 59 65 TE1	61.194.XX	61-0194-011	M23	923	0,99	0,35	Stift 01
Intercontec	97 59 65 TE1	61.194.XX	61-0194-011	M23	923	0,99	0,50	Stift 01
Intercontec	97 59 65 TE1	61.197.XX	61-0197-011	M40	940	1,14	0,35	Stift 04
Intercontec	97 59 65 TE1	61.197.XX	61-0197-011	M40	940	1,14	0,50	Stift 04
Intercontec	97 59 65 TE1	61.197.XX	61-0197-011	M40	940	1,32	0,75	Stift 04
Intercontec	97 59 65 TE1	61.197.XX	61-0197-011	M40	940	1,32	1,00	Stift 04
Intercontec	97 59 65 TE1	61.197.XX	61-0197-011	M40	940	1,50	1,50	Stift 04
Intercontec	97 59 65 TE1	61.197.XX	61-0197-011	M40	940	1,72	2,50	Stift 04
Intercontec	97 59 65 TE1	61.198.XX	61-0198-011	M40	940	0,81	0,14	Stift 04
Intercontec	97 59 65 TE1	61.198.XX	61-0198-011	M40	940	0,91	0,25	Stift 04
Intercontec	97 59 65 TE1	61.198.XX	61-0198-011	M40	940	0,99	0,35	Stift 04
Intercontec	97 59 65 TE1	61.198.XX	61-0198-011	M40	940	0,99	0,50	Stift 04
Intercontec	97 59 65 TE1	61.216.XX	61-0216-011	M23	923	0,99	2,50	Stift 01
Intercontec	97 59 65 TE1	61.216.XX	61-0216-011	M23	923	1,14	4,00	Stift 01